



Human Brain Project

5th Annual Human Brain Project Summit

18th - 20th October 2017
Scottish Exhibition Centre (SEC), Glasgow



Human Brain Project

5th Annual HBP Summit
Oct 18 - 20 2017
SEC, Glasgow, Scotland, UK

Hosted by
the University
of Glasgow




University
of Glasgow

Co-funded by
the European Union



Tutorial: BrainScaleS Neuromorphic Hardware

HBP Summit 2017




Eric Müller, Andreas Grübl

October 18, 2017

Kirchhoff-Institute for Physics, Heidelberg University

<https://github.com/electronicvisions/SpikeyNUC-workshop>



Human Brain Project

5th Annual HBP Summit
Oct 18 - 20 2017
SEC, Glasgow, Scotland, UK

Hosted by
the University
of Glasgow



University
of Glasgow

Co-funded by
the European Union



Introduction



Human Brain Project

5th Annual HBP Summit
Oct 18 - 20 2017
SEC, Glasgow, Scotland, UK

Hosted by
the University
of Glasgow



University
of Glasgow

Co-funded by
the European Union



Wifi:

ESSIDs: DemoBrainScaleS,
DemoBrainScaleS1, DemoBrainScaleS2
Password: BrainScaleS

Jupyter notebook hub:

<http://10.0.0.212>
(Pick a username, password is BrainScaleS)

GitHub:

<https://github.com/electronicvisions/SpikeyNUC-workshop>


Spikey school:

<http://10.0.0.212>

Analog Neuromorphic Hardware

1

observations




2

mathematical model

$$C \frac{dV}{dt} = -g_L (V - E_L) + I_{\text{syn}}(t)$$

3

hardware realization



Roadmap

2004

Spikey

single chip
system

384 LIF
neurons

2010

HICANN

180 nm
CMOS

512 AdEx
neurons

2015

20 Wafer System

4 million
neurons

0.9 billion
synapses

2017

HICANN DLS

65 nm
CMOS

32 neurons
integrated
CPU for pro-
grammable
plasticity

2018

HICANN DLS-SR

O(512)
neurons


2022

500 Wafer System

500 million
neurons

130 billion
synapses

System overview




FPGA:

- Field-programmable gate array
- reconfigurable logic gates
- experiment control and communication

Spikey:

- 384 neurons, 384×256 synapses
- speedup of 10^4

The analog core



Synapses:

- 4 bit weights (0...15)
- STDP and STP



Neurons:

- Leaky-integrate-and-fire model (LIF)
- analog parameters can be configured freely



Leaky-integrate-and-fire neurons

$$C_m \frac{dV_m}{dt} = -g_l(V_m - E_l) + I_{\text{syn}} + I_{\text{ext}}$$



Working with Spikey



Human Brain Project

5th Annual HBP Summit
Oct 18 - 20 2017
SEC, Glasgow, Scotland, UK

Hosted by
the University
of Glasgow



University
of Glasgow

Co-funded by
the European Union



<https://neuralensemble.org/docs/PyNN/0.7/api/api-0.7.html>

Look out for:

- `pynn.Population`
- `pynn.Projection`
- `pynn.*Connector`



Creating (groups of) neurons

Create *populations* of neurons:

```
params = {  
    "v_thresh": -60.0  
}  
neurons = pynn.Population(42, pynn.IF_facets_hardware1, cellparams=params)
```

Get a list of default neuron parameters:

```
print pynn.IF_facets_hardware1.default_parameters
```

Generating stimuli

Create a stimulus from a spike train:

```
spike_train = np.arange(10.0, 101.0, 10.0)
stimulus = pynn.Population(1, pynn.SpikeSourceArray, {"spike_times": spike_train})
```

There is also a Poisson spike source:

```
poisson_params = {
    "start": 10.0,
    "duration": 100.0,
    "rate": 5.0
}

stimulus = pynn.Population(1, pynn.SpikeSourcePoisson, poisson_params)
```



Synaptic connections

Connect all pre-synaptic to all post-synaptic neurons:

```
weight = 15 * pynn.minExcWeight()  
conn = pynn.AllToAllConnector(weights=weight)  
proj = pynn.Projection(pre, post, conn)
```

Specify connections in a list:

```
conn = pynn.FromListConnector([(7, 13, w, d), (42, 0, w, d)])
```

Other connectors (look at specification):

FixedNumberPreConnector

FixedNumberPostConnector

FixedProbabilityConnector

Recording observables

Spike times:

```
neurons.record()  
...  
spikes = neurons.getSpikes()
```

Analog membrane traces:

```
pynn.record_v(neurons[0], "")
```

- only *one* analog-to-digital converter (ADC)
→ one can record a single neuron at a time

Tasks

Task 1: a single neuron



- create a spike source
- create a single LIF neuron
- connect these two populations with maximum weight
- record spikes and the membrane trace of the stimulated neuron

1. vary the synaptic weight and observe the membrane trace
2. play around with the inter-spike interval of the stimulating spike train
3. observe how the PSPs stack up and eventually cause the neuron to fire

Task 2: passing spikes




- extend the network by adding another neuron
- record and plot the spikes of both neurons

1. think about different possibilities of creating and connecting the neurons
2. check that the stimulation is passed to the second neuron



Task 3: a closed synfire chain



- create ten excitatory and ten inhibitory **populations** of neurons and connect them as depicted
- create a transient stimulus to the zeroth excitatory population
- record and plot the spikes of the neurons
- record the membrane potential of a neuron of your choice

Task 3: a closed synfire chain


1. evaluate the stability of the chain by tweaking the weight parameters
2. what happens if you disconnect the inhibitory neurons?
3. modify the chain length




Task 4: a neural SR latch

Think about how to create a simple SR latch (set/reset latch).

S	R	Q
0	0	no change
0	1	Q = 0, reset state
1	0	Q = 1, set state
1	1	undefined



Task 4: a neural SR latch



- create a population of latch neurons and project them onto themselves
- create a transient excitatory and a transient inhibitory stimulus to the latch neurons
- set the stimuli such that the latch is switched on and off consecutively
- record and plot the spikes of the neurons
- record the membrane potential of a latch neuron